


### 3-6. Using the storage features

## List of storage features





- 1 Overhead console
- 2 Glove box
- 3 Bottle holders/door pockets
- 4 Cup holders
- 5 Console box/cup holder
- 6 Auxiliary box (if equipped)


### CAUTION

#### Items that should not be left in the storage spaces

Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:

-  Glasses may be deformed by heat or cracked if they come into contact with other stored items.
-  Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.

## Glove box



- 1 Open (push button)
- 2 Lock with the mechanical key
- 3 Unlock with the mechanical key

### Glove box light

The glove box light turns on when the “ENGINE START STOP” switch is in IGNITION ON mode.

### Trunk opener main switch


The trunk opener main switch is located in the glove box. (→ P. 50)

## CAUTION

### Caution while driving

Keep the glove box closed.  
Injuries may result in the event of an accident or sudden braking.

## Console box



- 1 Pull up the knob to release the lock.
- 2 Slide the armrest.
- 3 Pull up the knob to release the lock.
- 4 Lift the armrest to open.

■ Console box light

The console box light turns on when the “ENGINE START STOP” switch is in IGNITION ON mode.

■ Using the console box to store CD cases




Store a CD case with the hinged portion facing either the front or back of the console box.

**! CAUTION**

■ Caution while driving

Keep the console box closed.  
Injuries may result in the event of an accident or sudden braking.

**Overhead console**




Press the overhead console.


The overhead console is useful for temporarily storing sunglasses and similar small items.

**! CAUTION****■ Caution while driving**

Do not leave the overhead console open while driving.  
Items may fall out and cause death or serious injury in case of an accident or sudden stop.

**Cup holders****► Front (press-in type)**

Press down and release the front of the cup holder lid.

**► Front (slide type)**

**1** Pull up the knob to release the lock.

**2** Slide the armrest.

#### ► Rear



Press in and release the cup holders on the rear center armrest.

#### ■ Using the front cup holder (slide type) to store small items



Remove the cup holder insert by holding the base part.

#### ⚠ CAUTION


##### ■ Items unsuitable for the cup holder

Do not place anything other than cups or aluminum cans in the cup holders. Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury. If possible, cover hot drinks to prevent burns.

##### ■ When not in use

Keep the cup holders closed.  
Injuries may result in the event of an accident or sudden braking.

## Bottle holders/door pockets



The door pockets can be opened and closed.

When installing the bottle, close the cap of the bottle.

### ⚠ CAUTION

#### ■ Caution while driving

Keep the door pockets closed.  
Injuries may result in the event of an accident or sudden braking.

## Auxiliary box (if equipped)



Push the back part of the lid to open. Push the lid again to close.

### ⚠ CAUTION

#### ■ Caution while driving

Do not leave the auxiliary box open while driving.  
Items stored in it may fall out and cause death or serious injury in case of an accident or sudden stop.